

正反转型



F-5SM-8.5R



F-5SM-2R



F-6SM-2.5R~28R



F-8SM-12R~28R



F-8SM-8.5R

型号	失速扭矩			功率		空载转速	总长度		重量		耗气量 (空转)		空气软管尺寸	
	N.m	kgf.m	ft.lb	W	PS	min ⁻¹	mm	in	kg	lb	m ³ /min	ft ³ /min	mm	in
F-5SM-8.5R	5.4	0.55	4.0	120	0.16	850	147	5 51/64	0.6	1.3	0.28	9.9	6.3	1/4
F-5SM-2R	21.6	2.20	15.9	100	0.14	190	182	7 11/16	0.8	1.8	0.28	9.9	6.3	1/4
F-6SM-28R	3.3	0.34	2.5	250	0.34	2,300	147	5 51/64	0.8	1.8	0.34	12.0	8.0	5/16
F-6SM-21R	4.0	0.41	3.0	260	0.35	2,000	146	5 3/4	0.9	2.0	0.34	12.0	8.0	5/16
F-6SM-12R	5.9	0.60	4.3	230	0.31	1,000	157	6 3/16	0.8	1.8	0.34	12.0	8.0	5/16
F-6SM-8R	9.8	1.00	7.2	230	0.31	750	179	7 1/16	1.0	2.2	0.34	12.0	8.0	5/16
F-6SM-5R	14.7	1.50	10.8	220	0.30	500	180	7 3/32	1.0	2.2	0.34	12.0	8.0	5/16
F-6SM-2.5R	26.0	2.65	19.2	210	0.29	250	192	7 9/16	1.2	2.6	0.34	12.0	8.0	5/16
F-8SM-28R	6.4	0.65	4.7	380	0.52	2,300	183	7 13/64	1.5	3.3	0.50	17.7	9.5	3/8
F-8SM-12R	9.8	1.00	7.2	370	0.50	1,100	199	7 53/64	2.2	4.8	0.50	17.7	9.5	3/8
F-8SM-8.5R	14.7	1.50	10.8	370	0.50	850	222	8 3/4	2.4	5.3	0.50	17.7	9.5	3/8

进气螺纹尺寸: PT或NPT 1/8" (除 F-8SM-系列 1/4")

订购时请指定主轴形式